

How to update my Iridium

copy the file [iridium.update.bin](#) into the main directory of an USB drive. The drive doesn't have to have any special certifications. [Use FAT or EX FAT format](#). You will need less than 20MB of free space on the drive.

Connect the USB drive to the **Controller** port on your Iridium. Then press [Global/System/Update](#) and select the .bin file. Iridium now processes the update automatically. During the process, do not touch any of the controls on the device, do not send MIDI data and most important, do not switch off the device and do not cut the power. The whole process takes less than a minute.

Wie führe ich ein OS Update am Iridium durch

kopiere die Datei [iridium.update.bin](#) in das Hauptverzeichnis eines USB-Sticks. Der Datenträger braucht keine bestimmte Spezifikation zu haben, sollte aber [FAT oder EX-FAT](#) formatiert sein. Es werden weniger als 20MB freier Speicherplatz auf dem Datenträger benötigt.

Verbinde das USB-Gerät mit dem **Controller**-Anschluss vom Iridium. Gehe auf [Global/System/Update](#) und wähle die [iridium.update.bin](#) Datei aus. Iridium beginnt nun selbstständig mit dem Update. Währenddessen keine Bedienelemente betätigen, keine MIDI Daten senden und auf keinen Fall das Gerät ausschalten oder die Stromzufuhr unterbrechen. Die gesamte Prozedur dauert üblicherweise weniger als eine Minute.