

## How to update my Iridium Keyboard

copy the file [iridium-keyboard.update.bin](#) into the main directory of a USB drive or a MicroSD card. The drive doesn't have to have any special certifications. [Use FAT or EX FAT format](#). You will need less than 20MB of free space on the drive.

Connect the USB drive to the controller port on your Iridium or carefully insert the MicroSD card into the corresponding slot. The card needs to be inserted with the upside downwards and the contacts facing upwards. Gently insert the card and avoid jamming it. The card clicks into place when inserted correctly.

On Iridium, press [Global/System/Update](#) and select the .bin file. Iridium now processes the update automatically. During the process, do not touch any of the controls on the device, do not send MIDI towards Iridium and most important, do not switch off the device and do not cut the power. The whole process takes less than a minute.

After the firmware update, it may be necessary to recalibrate the pitchbend and modwheel. > **Global/System/Calibrate**

## Wie führe ich ein OS Update am Iridium Keyboard durch

kopiere die Datei [iridium-keyboard.update.bin](#) in das Hauptverzeichnis eines USB-Sticks, einer USB-Festsplatte oder einer Micro-SD-Karte. Der Datenträger braucht keine bestimmte Spezifikation zu haben, sollte aber [FAT](#) oder [EX-FAT](#) formatiert sein. Es werden weniger als 20MB freier Speicherplatz auf dem Datenträger benötigt.

Verbinde das USB-Gerät mit dem Controller-Anschluss von Iridium bzw. stecke die Micro-SD-Karte in den dafür vorgesehenen Slot. Die Karte muss mit der Oberseite nach unten und mit den Kontakten nach oben in den Slot eingeschoben werden. Gehe hierbei vorsichtig vor und vermeide ein Verkanten der Karte. Die Karte rastet mit einem Klicken ein, wenn sie korrekt eingesetzt ist.

Gehe auf [Global/System/Update](#) und wähle die .bin Datei aus. Iridium beginnt nun selbstständig mit dem Update. Währenddessen bei Iridium keine Bedienelemente betätigen, kein MIDI ans Gerät senden und auf keinen Fall das Gerät ausschalten oder die Stromzufuhr unterbrechen. Die gesamte Prozedur dauert üblicherweise weniger als eine Minute.

Nach dem Firmwareupdate ist es gegebenenfalls notwendig, Pitchbend und Modwheel neu zu kalibrieren. > **Global/System/Calibrate**