

## Waldorf Wave MIDI Implementation Chart

Function		Transmitted	Recognized	Remarks
Basic Channel	Default Changed	1 1 - 16	1 1 - 16	
Mode	Default Messages Altered	x x	2 x x	No Modes supported
Note Number	True Voice	0 - 127	0 - 127 0 - 108	
Velocity	Note ON Note OFF	o o	o o	
After Touch	Key's Ch,s	x o	o o	
Pitch Bender		o	o	
Control Change	0 1 7 10 64 0 - 120	o o o o o o	o o o o o o	Bank Switch Mod. Wheel Main Volume Panning Sustain Pedal Assignable to Buttons,Faders and Free Wheel
Program Change	True #	o	o 0 - 127	P.-Change via Editable Maps
System Exclusive		o	o	
System Common	Song Pos. Song Sel. Tune	x x x	x x x	
System	Clocks	x	o	Clock usable as modulator
Real time	Commands	x	x	
Aux Mes-sages	Local ON/OFF All Notes Off Active Sense Reset	x o o x	x o o x	selectable
Notes	Supports MIDI Tuning Standard			

Mode 1: OMNI ON,POLY  
Mode 2: OMNI OFF,POLY

Mode 3: OMNI ON,MONO  
Mode 4: OMNI OFF,MONO

o : Yes  
x : No